PİZZERİA PRONTO MARKA. ARKA TARAFINDA UFAK BOYA DÖKÜLMESİ VARDIR. TEHŞİR ÜRÜNÜ.

Stok Numarası: 456310

PIZZERIA
Piamo
OUTDOOR PIZZA OVEN

PIZZERIA
OUTDOOR PIZZA OVEN
COOL
PRE-HEATING
PIZZA COOKING ZONE
500°
700°
900° F
260°
371°
482° C




Outdoor Pizza Oven
Model No.: PC6000
The Companion Group
LIGHTING INSTRUCTIONS:
1. Connect the gas cylinder to the gas regulator. 2. Turn the knob counterclockwise to ignite. 3. If ignition DOES NOT OCCUR within 5 seconds, turn off burner control(s).

PIZZERIA
OUTDOOR PIZZA OVEN